1. General information

Thank you for chosing our product to grow your garden beauty! We wish enjoy your time in our product.

You have the assembly instruction in your hands. **Please read it carefully before proceeding with the garden house installation.** If you do it you will avoid problems and not waste your time.

Recommendations:

- Packed product is protected from rain and all details are all together. SO, keep the product package until start the assembly in a dry place, but do not keep it in direct sun or heated room. Product must be on pallet and the pallet must be on dry ground.
- Two carpenters at least can assemble the garden house.
- Prepare place for the garden house. It must be clean and straight. We recommend prepare good foundation.

2. Warranty

All our products are made from high quality wood and delivered in natural form. If, despite our thorough inspection, you should have complains, please send us reclamation together with purchase invoice to the product seller.

The warranty does not cover:

- Peculiarities of wood as natural material
- Wooden details already painted (processed with a wood preservative)
- Wooden details containing whole branches that do not endanger the stability of the product.
- Poof and floor boards that may have in their concealed surfaces some non-planned areas, colour differences and waning
- Self-initiative changes to the house, such a changed form of wooded details and doors/windows due to an incompetent manner of wood processing.

All complaints which are covered by the warranty are solved by replacing faulty materials.

3. Painting and maintenance of the product

- You should not forget that wood is a natural material, it change move depending on weather conditions. Large and small cracks, color tone differences and changes, as well as a changing structure of wood are not errors, but a result of wood growing and a peculiarity of wood as a natural material.
- Natural wood (not impregnated) becomes grayish after having been left untouched for a while, and can be turn blue and become moldy. You should immediately process them with wood impregnations to protect the wooden details of our produced products.
- We definitely recommend that you process the door and windows with a wood impregnation agent, and do it namely both inside and outside, because the doors and windows can become twisted. In general, we recommend for the conclusive finishing a weather protection paint that will protect wood from moisture and UV radiation after the house is assembled.

- Consult a specialist regarding paints suitable for unprocessed softwood and follow the paint manufacturer's instructions.
- Your garden house life time will be much longer after having properly painted. We recommend that you inspect the house thoroughly once every six month.

4. Preparation for assembly

Tools needed to assembly the garden house:

Drill	
Meter	
Knife	
Level	
Saw	
Hammer	
Saw	


5. Using recommendation:

NB! Be very careful while grilling and making fire indoors or in shelters and kotas!

- When using your grill for the first time, the surfaces of the new product that are in direct contact with the flames may create smoky smell while warming-up, because the paint is drying finally. We advise to keep the door open during the first usage and not to cook until the smell has cleared.
- The paint used Temal 400 bears dry heat up to +400 degrees centigrade. The final drying proceeds at the temperature +230 degrees. The paintdoes not consist of unhealthy compounds and no chemicals hazardous to health are released during heating. Some splitting and burning of the paint is normal, because in the long run the paint does not bear the heat of the flames.
- When using the grill avoid direct contact with the steel parts of the grill, because there are the risk to burn your hands or other parts of your body. The parts of the grill may have sharp edges, therefore be customarily careful.
- To start the fire place a couple of small, dry birch logs on the fire grate. To get good ember we advise to add some charcoal as well. We suggest to use natural materials, starter cubes or a little lighter fluid for lighting the fire. Tomake it more easy and to ensure that the grill is getting enough replacement

air open the damper and it is adviseable to keep the door open as well. In case the hood gets warmer the draught will be better and then the bigger logs can be added.

- In order to achieve optimal ember, regulate the ventilation with opening and closing the damper. Choose a non-sparking wood type; avoid using spruce or aspen and wood covered with bark. We advise to use logs with max length 300 mm.
- Sufficient fresh airflow is most essential aspect of smoke exhaustion. At least as much fresh air should come in as goes out with the smoke. If the grill is smoking open the door of the cottage and make sure that the wood is dry or not bark covered. Provide additional dry wood if needed.
- Remove coals and ashes from the fireplace afterthey have cooled down.



1. GARDEN PAVILION- 9.2			
No.	x z Detail	Pcs	Dimention (x, y, z) mm
1		6	70 x 1880 x 46
2		1	1880 x 1880 x 45
3		3	1880 x 1880 x 45
4		2	1880 x 1880 x 45
5		6	1880 x 195 x 16
6		6	195 x 2053 x 45
7	₽	6	70 x 240 x 45
8		6	1930 x 1855 x 45
9		6	300 x 2240 x 12
10		6	70 x 2090 x 18
(11)		6	70 x 1520 x 18
(12)	4	1	200 x 1000
13		3	1530 x 1796 x 36
14		6	70 x 1828 x 18
(15)	P	15	310 x 310 x 115
(16)		2	70 x 2246 x 45
(17)		2	70 x 1828 x 45

	2. GARDEN PAVILION- 9.2		
No.	x z Detail	Pcs	Dimention (x, y, z) mm
(18)		1	70 x 1412 x 45
(19)		2	195 x 1940 x 45
20		2	195 x 1940 x 45
21		3	195 x 1828 x 45
22		3	195 x 1591 x 45
23		2	195 x 1580 x 45
24		4	310 x 45 x 70
25		3	390 x 1828 x 50
26		2	390 x 2053 x 50
27)		1	722 x 1000 x 55
28		1	a) 250 x 570 x 493 b) 900 x 380 x 329
29		1	140 x 570 x 493
30		1	900 x 356 x 308
31		1	440 x 1020 x 883
32	8	1	

3. GARDEN PAVILION- 9.2				
No.	x 2 Detail	Pcs	Dimention (x, y, z) mm	
33		1	608 x 680 x 588	
34	-	2	50 x 325 x 2	
35		6	225 x 600 x 18	
36	Ϋ́	6	19 x 69 x 30	
37	-	6	15 x 215x 23	
38	a[🛞	1	a) 675 x 780 x 180	

	4. GARDEN PAVILION- 9.2			
No.	x Z Detail	Pcs	Dimention (x, y, z) mm	
A2		86	335 x 250 x 3	
(A3)		62	5 x 100	
(A4)		40	6 x 80	
A 5	-	140	4 x 70	
A6	-	136	3.5 x 45	
A7	-	45	3 x 30	
A8	-	20	3 x 16	
A9	-	20	4.2 x 13	
(A10)	En .	350	2.5 x 20	
A11	~	3	2 x 50	
(A12)	~ *	3	4 x 53	
(A13)		1	315 x 640 x 25	
(A14)	—	2	195 x 595 x 25	
A15		3	12 x 1300	
(A16)	\$	3	AVI	
(A17)	00	2		
(A18)	1	1		
(A19)		4	39 x 38 x 2	

